

WFS2 Water Fill Valve Installation Instructions

To install the water fill valve you will need to drill a $1\frac{1}{8}$ " hole in the back of the skimmer wall. The hole can be located anywhere that is convenient inside the pump chamber. The hole should be centered 4" down from the top lip of the skimmer. Install the threaded portion of the fill valve through the hole from the inside of the skimmer. Apply a small amount of pipe compound or teflon tape (or if all else fails use silicone caulk) to the threads and tighten the gray adapter to the fill valve. This fitting will accept $\frac{3}{4}$ " irrigation tubing. The height of the water can be controlled by adjusting the float up or down.